

PP	Sendername	Frequenz	Pol.	SR	FEC
001	Das Erste HD	11494 MHz	H	22000	2/3
002	ZDF HD	11362 MHz	H	22000	2/3
003	RTL HD	10832 MHz	H	22000	2/3
004	SAT.1 HD	11464 MHz	H	22000	2/3
005	ProSieben HD	11464 MHz	H	22000	2/3
006	kabel eins HD	11464 MHz	H	22000	2/3
007	RTLII HD	10832 MHz	H	22000	2/3
008	VOX HD	10832 MHz	H	22000	2/3
009	arte HD	11494 MHz	H	22000	2/3
010	3sat HD	11347 MHz	V	22000	2/3
011	WDR HD Köln	12422 MHz	H	27500	3/4
012	NDR FS NDS HD	11582 MHz	H	22000	2/3
013	BR Süd HD	11582 MHz	H	22000	2/3
014	SWR BW HD	11494 MHz	H	22000	2/3
015	hr-fernsehen HD	10891 MHz	H	22000	2/3
016	MDR Sachsen HD	10891 MHz	H	22000	2/3
017	rbb Berlin HD	10891 MHz	H	22000	2/3
018	Disney Channel HD	10802 MHz	H	22000	3/4
019	KiKA HD	11347 MHz	V	22000	2/3
020	SUPER RTL HD	11082 MHz	H	22000	3/4
021	SPORT1 HD	10802 MHz	H	22000	3/4
022	Eurosport Deutschland	12226 MHz	H	27500	3/4
023	TELE 5 HD	12574 MHz	H	22000	2/3
024	NICKELODEON HD	10773 MHz	H	22000	3/4

025	RTLNITRO HD	11082 MHz	H	22000	3/4
026	PHOENIX HD	11582 MHz	H	22000	2/3
027	ServusTV HD Deutschland	11303 MHz	H	22000	2/3
028	zdf_neo HD	11362 MHz	H	22000	2/3
029	EinsPlus HD	11053 MHz	H	22000	2/3
030	Einsfestival HD	11053 MHz	H	22000	2/3
031	tagesschau24 HD	11053 MHz	H	22000	2/3
032	ZDFinfo HD	11347 MHz	V	22000	2/3
033	zdf.kultur HD	11362 MHz	H	22000	2/3
034	ARD-alpha	12266 MHz	H	27500	3/4
035	N24 HD	10773 MHz	H	22000	3/4
036	n-tv HD	10832 MHz	H	22000	2/3
037	ANIXE HD	10773 MHz	H	22000	3/4
038	Comedy Central/VIVA	11973 MHz	V	27500	3/4
039	TLC HD	10964 MHz	H	22000	2/3
040	SAT.1 Gold	12545 MHz	H	22000	5/6
041	ProSieben MAXX HD	11464 MHz	H	22000	2/3
042	SIXX HD	11464 MHz	H	22000	2/3
043	DMAX HD	12574 MHz	H	22000	2/3
* Stand: 13. Oktober 2014					